HOW TO...

Open the Yukon TV app:

Navigate to the app in your Amazon Fire TV Cube home screen

Set a recording:

❶ In the Live TV channel guide, select the show you wish to record

❷ Click on the show and scroll to highlight the "record" option and click

❸ The show will now have a red icon to indicate it is set to record

Access Video on Demand:

❶ Click on "VOD" from the home screen menu

Additional support available at **gci.com/support**.

View the complete Yukon TV channel lineup.

Visit **gci.com/tv/channel-line-up**

Personalize your Yukon TV package with more of the content you love.

Genre tiers and premium channels are available to upgrade your experience.

Explore your options at **gci.com/tv**

Let your Yukon TV experience take you further.

Upgrade your viewing features to include more simultaneous streams and cloud DVR hours.

Need help?

Just give us a call:
800.800.4800

YUKON TV

Getting Started with Yukon TV

on Amazon Fire TV Cube Streaming Device

Alaska's Ultimate Streaming Experience

GCI

STEP-BY-STEP GUIDE

1 **Package Contents:**

    1 Fire TV Cube

    2 Alexa Voice Remote

    3 Ethernet adapter

    4 IR extender cable

    5 Power adapter

2 **Use the HDMI cable to connect the Amazon Fire TV Cube device to your TV.**

3 **Using the power cord, plug in the Amazon Fire TV Cube.**

4 **Follow the on-screen instructions using your remote to navigate through the setup process. You'll need:**

- A Yukon TV account and GCI Home Internet.

  Note: Streaming on Yukon TV does not count against your GCI home internet usage.

- An active Amazon account.

- To be registered on MyGCI.

  Note: Visit my.gci.com to get started.

5 **Download the Yukon TV app from the App Store.**

6 **Sign into your Yukon TV account using your MyGCI login credentials.**

7 **Start watching your favorite shows on Yukon TV!**

After completing installation, tear off this sheet to use as a quick reference guide for your remote.

YUKON TV REMOTE GUIDE

Power Button

Alexa Voice Search

Navigation

Select

Home

Back

Menu

Rewind

Fast Forward

Volume Up

Play/ Pause

Volume Down

Mute

GCI